

skriňa RS2 v RD2 pri St.1

15	EZ3-1/2D		EZ3-TZ		EZ3-P		EZ4-3/4D		EZ4-TZ		EZ4-P						panel voľnej väzby 72 571c				
	NMŠ1-2000		NMŠM1-1500		NMŠ1-2000		NMŠ1-2000		NMŠM1-1500		NMŠ1-2000										
	01		02		03		04		05		06		07		08						
14	EZ5-6D		EZ5-TZ		EZ5-P		EZ6-5D		EZ6-TZ		EZ6-P						panel voľnej väzby 72 571c				
	NMŠ1-2000		NMŠM1-1500		NMŠ1-2000		NMŠ1-2000		NMŠM1-1500		NMŠ1-2000										
	01		02		03		04		05		06		07		08						
13	1LCS		1LBS		Pr1LYS		1LPn		RS		RSQ		RSQ1		SK		panel voľnej väzby 72 571c				
	NMŠ2-60		NMŠ2-60		NMŠ2-60		NMŠM1-1500		NMŠ2-4000		NMŠM1-1500		NMŠ1-2000		NMŠ1-2000						
	01	D1	02	D1	03	D1	04	R1,C4,-,-,-	05	R5,D2,-,-	06		07		08						
12	2LN		2LNO		2LDS		2LPn		2LHm		2LGm		2LG4				panel voľnej väzby 72 571c				
	NMŠ1-2000		NMŠ1-2000		NMŠM1-1500		NMŠM1-1500		NMŠ1-2000		NMŠ1-2000		NMŠ1-2000								
	01	R1,C4,-,R1,C4	02		03	R3,R3,-,-,-	04	R1,C4,-,R1,C4	05		06	R1,C4,-,R1,C4	07		08						
11	2L1YS		2LZS		2LCS		2LBS		2L2YS		Pr2LYS		Pr2LZS				panel voľnej väzby 72 571c				
	NMŠ2-60		NMŠ2-60		NMŠ2-60		NMŠ2-60		NMŠ2-60		NMŠ2-60		NMŠ2-60								
	01	D1	02	D1	03	D1	04	D1	05	D1	06	D1	07	D1	08						
10	1LCS	1LCS	1LBS	Pr1LYS	Pr1LYS	2L1YS	2LZS	2LCS	2LBS	2L2YS	Pr2LYS	Pr2LYS	Pr2LZS					KON	panel poistiek a odporov 726439002		
	0,16A	ZDR	0,16A	0,16A	ZDR	0,16A	0,16A	0,16A	0,16A	0,16A	0,16A	ZDR	0,16A					DC/DC			
	01	02	03	04	05	06	07	08	09	10	11	12	13					21			
09	J1	J2	J3	J4	J5	J6	J7	J8	J9	J10	J11	J12	J13	J14	J15	J16	J17	J18	J19		panel ističov a ochrán 72 643b
	10A	6A	6A	0,5A	0,16A	0,16A	0,5A	0,5A	0,5A	5A	5A	5A	2A	1A	1A	1A	1A	1A	5A		
	0T	L/N	P230/2230	HIS	HNB+	HNB-	BZKS	POBS	POBS	+/-	S	SK	DC/DC	+T/-T	EZ3	EZ4	EZ5	EZ6	PO		
	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19		
08	RSI		ZNN		KNM		DK						HNB				panel voľnej väzby 72 571c				
	NMŠM1-1500		NMŠ1-2000		NMŠ1-2000		NMŠ1-2000						č.v. 71 972a								
	01	C1,R4,-,C3,R4	02		03	71993 5 408	04	Ds759	05		06		07		08						
07	<div><div></div><div>BZKS20-3.2S</div><div></div></div> <div><div>C</div><div>2M/630V</div><div></div></div> <div><div></div><div>POBS3</div><div></div></div> <div><div></div><div>HIS</div><div>č.v.60094b</div></div>																polica dvojité				
06																					
05	<div><div></div><div>EZ2 73310 9 001</div><div>1 x 0,3kVA</div></div> <div><div></div><div>VT1</div><div></div></div> <div><div></div><div>OT</div><div>1kVA</div></div>																polica dvojité				
04																					
03	N2,3,5-J		N2,3,5-RES		N1,4,6-J		N1,4,6-RES		K2-J		K2-RES		K4-J		K4-RES		panel voľnej väzby 72 571c				
NMŠ1-2000		NMŠ1-2000		NMŠ1-2000		NMŠ1-2000		NMŠ1-2000		NMŠ1-2000		NMŠ1-2000		NMŠ1-2000							
01	D,-,-,-	02		03	D,-,-,-	04		05	D,-,-,-	06		07	D,-,-,-	08							
02	<div>Panel počítača osí PN1-ACS2000, skriňa BGT06-126TE</div>																polica dvojité				
01																					
01																	72 482d				

pozn.: - poschodia č.16,17 sú umiestnené na zadnej stene skrine RS

- R1 - 150/8W

R2 - 150/15W

R3 - 3k3/25W

R4 - 39/2W

R5 - 12k/15W

R6 - 100R/6W
- C1 - 470M/40V

C2 - 1G/40V

C3 - 2G/40V

C4 - G5/40V

C5 - 4G7/40V

C6 - 1000M/40V

C7 - 22M/40V
- D - 1N4007

D1 - 1N4007 pripájať na vývody 11,03 - katódou na 03

D2 - KY132/600

16
<div><div>BSI-12</div><div>BSI-11</div><div>BSI-10</div><div>BSI-9</div><div>BSI-8</div><div>BSI-7</div><div>BSI-6</div><div>BSI-5</div><div>BSI-4</div><div>BSI-3</div><div>BSI-2</div><div>BSI-1</div></div> <div><div>BSI002</div><div>BSI002</div><div>BSI002</div><div>BSI002</div><div>BSI002</div><div>BSI002</div><div>BSI002</div><div>BSI002</div><div>BSI002</div><div>BSI002</div><div>BSI002</div><div>BSI002</div></div> <div><div>12</div><div>11</div><div>10</div><div>09</div><div>08</div><div>07</div><div>06</div><div>05</div><div>04</div><div>03</div><div>02</div><div>01</div></div>
17
<div><div></div><div>6xGND</div></div> <div><div>P0K0-94</div><div>01</div></div>

SVORKOVNICE WEIDMULLER 1x16x10, 14x12x2,5