

Diagram of a 22-row server rack layout. The rows are numbered 1 to 22 on the left. The components are distributed as follows:

- Row 1: VENTILACNA JEDNOTKA
- Row 2: Empty
- Row 3: Empty
- Row 4: Empty
- Row 5: VX-3008F
- Row 6: Empty
- Row 7: Empty
- Row 8: Empty
- Row 9: VX-3000DS
- Row 10: Empty
- Row 11: Empty
- Row 12: Empty
- Row 13: POLICA
- Row 14: Empty
- Row 15: Row with 6 drive bays (each with a circular icon) and two empty bays
- Row 16: Empty
- Row 17: Empty
- Row 18: AKUMULATOR
- Row 19: Empty
- Row 20: Empty
- Row 21: Empty
- Row 22: Empty

